

Product Guide

Find the right product for your device

device

	AP1201	AP1202	AP1500	AP750	XP1000	XP2000	XP2000K Travel Kit	XP4000	XP4001	XP8000	XP18000
Cell Phone					•	•	•	•	•	•	•
Smart Phone				•	•	•	•	•	•	•	•
iPhone 4	•				•	•	•	•	•	•	•
iPhone 3, 3GS			•			•	•	•	•	•	•
iPod, mp3						•	•	•	•	•	•
iPod Touch		•				•	•	•	•	•	•
e-Reader						•	•	•	•	•	•
GPS								•	•	•	•
Digital Camera								•	•	•	•
Camcorder								•			
Gaming						•	•	•	•	•	•
Bluetooth®					•	•	•	•	•	•	•
Netbook										•	•
Laptop											•
Tablet										•	•

Energizer® energi to go®